


TGB 8572

BRUSH DECK COVER



Fitting Instructions

Warning! Read instructions before using the machine




TGB 8572 BRUSH DECK COVER FITTING INSTRUCTIONS

PLEASE READ BEFORE COMMENCING OPERATION

After the removal of all the packaging, carefully open and check the contents

- 1 x Left Hand Brush Deck.
- 1 x Right Hand Brush Deck.
 - 1 x Centre Deck Cover.
- 6 x No.8 S/S Screw 1 inch.
 - 6 x M5 Washer.
- 4 x No.8 S/S Screw 1/2 inch

Tools Needed
Pozi Drive Screw Driver.




6 x No.8 x 1 inch Stainless Steel Screws.


6 x M5 Form G Stainless Steel Washers.

4 x No.8 x 1/2 inch Stainless Steel Screws.

Operators Perspective




Left Hand Brush Deck Cover Assembly.
Right Hand Brush Deck Cover Assembly.
Centre Brush Deck Cover Assembly




TGB 8572 face on view out of the box
with no decks fitted.


TGB 8572 BRUSH DECK COVER FITTING INSTRUCTIONS




Locate the Right Hand Brush Deck Cover onto the Right Hand side of the brush mount. Make sure the elbow fitting is fully located under the cover of the brush deck.



Attach Right Hand Brush Deck Cover using 3 x 1 inch screws and washers into the fixing points shown above. Repeat the same with the other deck cover on the Left Hand side.



Locate the Centre Brush Deck Cover and place onto in the centre of the brush deck. Make sure the corners of the deck cover go under the raised centres of the left and right deck covers (Fig.1) and (Fig.2).




Attach the Centre Brush Deck Cover using the 4 x 1/2 inch screws into the fixing points shown above.

Distributed by:



Numatic International Limited.
Chard, Somerset TA20 2GB ENGLAND
Tel: 01460 68600 www.numatic.co.uk




Numatic International GmbH. Fränkische Straße 15–19
D-30455 Hannover, DEUTSCHLAND
Tel: 05 11 98 42 16 0 www.numatic.de



Numatic International SAS. EAE La Tuilerie – 13 / 17 rue du Valengelier
77500 CHELLES, FRANCE
Tel: 01 64 72 61 61 www.numatic.fr




BeNeLux Distribution, Numatic International BV
Postbus 101, 2400 AC Alphen aan den Rijn, NEDERLAND
Tel: 0172 467 999 www.numatic.nl



Numatic International (Pty.) Ltd.
16th & Pharmaceutical Roads, Midrand, Gauteng,
SOUTH AFRICA 1685
Tel: 0861 686 284 www.numatic.co.za



Numatic International Schweiz AG.
Sihlbruggstrasse 3A, 6340 Baar. SCHWEIZ
Tel: 0041 (0) 41 76 80 76 - 0 www.numatic.ch



Numatic International ULDA. Rua da Boa Viagem, 177
4470.210 Maia. PORTUGAL
Tel: +351 220 047 700 www.numatic.pt



Numatic International SLU. C/ La Forja, 41, 08840 Viladecans
(Barcelona), Spain
Tel: +34 93 647 22 22 www.numatic.es

This Product has been comprehensively inspected and checked during every stage of its manufacture,
including an in-depth electrical safety and functionality test.

Specification subject to change without prior notice
www.numatic.co.uk © Numatic International Limited

906900 12/20 (A02)